

PRODUCT CERTIFICATIONS

DECLARATION OF CONFORMITY & INSTALLATION INSTRUCTIONS

Please use the following chart to locate and download the correct Attestation of Conformity and/or Installation Instructions for your Ai-Tek Sensor from the Product Certifications page.

AI-Tek SENSOR	Declaration of Conformity	Installation Instructions	Class 1 Zone 1	Class 1 Zone 2	Class 1 Division 1	Class 1 Division 2
70085-1010-005	960-0134-001	960-0135-001	X		X	
70085-1010-081	960-0115-001	960-0101-001	X		X	
70085-1010-327	960-0134-001	960-0135-001	X		X	
70085-1010-329	960-0115-001	960-0101-001	X		X	
70085-1010-330	960-0134-001	960-0135-001	X		X	
70085-1010-411	960-0134-001	960-0135-001	X		X	
70085-1010-412	960-0134-001	960-0135-001	X		X	
70085-1010-413	960-0134-001	960-0135-001	X		X	
70085-1010-414	960-0134-001	960-0135-001	X		X	
70085-1010-403	960-0124-001	960-0125-001		X		X
70085-1010-404	960-0124-001	960-0125-001		X		X
70085-1010-405	960-0124-001	960-0125-001		X		X ¹
70085-1010-406	960-0124-001	960-0125-001		X		X ^{on2}
70085-1010-415	960-0124-001	960-0125-001		X		X
70085-1010-416	960-0124-001	960-0125-001		X		X
70085-1010-417	960-0124-001	960-0125-001		X		X
70085-1010-420	960-0124-001	960-0125-001		X		X
70085-3030-XXX	960-0129-001	960-0130-001			X	
RH1512-026	960-0118-001	960-0109-001			X	
RH1512-027	960-0118-001	960-0109-001			X	
RH1522-026	960-0118-001	960-0109-001			X	
RH1522-027	960-0118-001	960-0109-001			X	
RH1612-026	960-0118-001	960-0109-001			X	
RH1612-027	960-0118-001	960-0109-001			X	
RH1622-026	960-0118-001	960-0109-001			X	
RH1622-027	960-0118-001	960-0109-001			X	