

PRODUCT CERTIFICATIONS

DECLARATION OF CONFORMITY & INSTALLATION INSTRUCTIONS

Please use the following chart to locate and download the correct Attestation of Conformity and/or Installation Instructions for your Ai-Tek Sensor from the Product Certifications page.

AI-Tek SENSOR	ATTESTATION OF CONFORMITY	INSTALLATION INSTRUCTIONS	ATEX	UL	CSA	FM
70085-1010-005	960-0134-001	960-0135-001	X	X	X	
70085-1010-081	960-0115-001	960-0101-001	X	X	X	
70085-1010-327	960-0134-001	960-0135-001	X	X	X	
70085-1010-328	960-0134-001	960-0135-001	X	X	X	
70085-1010-329	960-0115-001	960-0101-001	X	X	X	
70085-1010-330	960-0134-001	960-0135-001	X	X	X	
70085-1010-403	960-0117-001	960-0112-001	X			X
70085-1010-404	960-0124-001	960-0125-001	X			X
70085-1010-405	960-0117-001	960-0112-001	X			X
70085-1010-406	960-0124-001	960-0125-001	X			X
70085-1010-411	960-0134-001	960-0135-001	X	X	X	
70085-1010-412	960-0134-001	960-0135-001	X	X	X	
70085-1010-413	960-0134-001	960-0135-001	X	X	X	
70085-1010-414	960-0134-001	960-0135-001	X	X	X	
70085-1010-415	960-0134-001	960-0135-001	X			X
70085-1010-416	960-0117-001	960-0112-001	X			X
70085-1010-417	960-0124-001	960-0125-001	X			X
70085-1010-420	960-0124-001	960-0125-001	X			X
70085-3030-xxx	960-0129-001	960-0130-001	X			
RH1512-026	960-0118-001	960-0109-001	X	X	X	
RH1512-027	960-0118-001	960-0109-001	X	X	X	
RH1522-026	960-0118-001	960-0109-001	X	X	X	
RH1522-027	960-0118-001	960-0109-001	X	X	X	
RH1612-025	960-0118-001	960-0109-001	X	X	X	
RH1612-026	960-0118-001	960-0109-001	X	X	X	
RH1612-027	960-0118-001	960-0109-001	X	X	X	
RH1622-026	960-0118-001	960-0109-001	X	X	X	
RH1622-027	960-0118-001	960-0109-001	X	X	X	