

BH SERIES

Active Sensor (Bi-Dir.) Selection Guide

Thread Size	Part Number	Supply Tracking or TTL	Termination	Thread Length (in)	Sensor Length (in)	Page
3/4-20	BH1612-001	TTL	Connector	1.5	3.375	40
3/4-20	BH1622-001	ST	Connector	1.5	3.375	40
3/4-20	BH1612-002	TTL	Connector	2.75	4.625	40
3/4-20	BH1622-002	ST	Connector	2.75	4.625	40
3/4-20	BH1612-013	TTL	Cable	1.5	3.375	40
3/4-20	BH1622-013	ST	Cable	1.5	3.375	40
3/4-20	BH1612-014	TTL	Cable	2.75	4.625	40
3/4-20	BH1622-014	ST	Cable	2.75	4.625	40
3/4-20	BH1612-005	TTL	Connector	1.5	3.375	41
3/4-20	BH1622-005	ST	Connector	1.5	3.375	41
3/4-20	BH1612-006	TTL	Connector	2.75	4.625	41
3/4-20	BH1622-006	ST	Connector	2.75	4.625	41
3/4-20	BH1612-009	TTL	Cable	4	4	41
3/4-20	BH1622-009	ST	Cable	4	4	41
3/4-20	BH1612-010	TTL	Cable	6	6	41
3/4-20	BH1622-010	ST	Cable	6	6	41
5/8-18	BH1512-001	TTL	Connector	1.5	3.375	40
5/8-18	BH1522-001	ST	Connector	1.5	3.375	40
5/8-18	BH1512-002	TTL	Connector	2.75	4.625	40
5/8-18	BH1522-002	ST	Connector	2.75	4.625	40
5/8-18	BH1512-013	TTL	Cable	1.5	3.375	40
5/8-18	BH1522-013	ST	Cable	1.5	3.375	40
5/8-18	BH1512-014	TTL	Cable	2.75	4.625	40
5/8-18	BH1522-014	ST	Cable	2.75	4.625	40
5/8-18	BH1512-005	TTL	Connector	1.5	3.375	41
5/8-18	BH1522-005	ST	Connector	1.5	3.375	41
5/8-18	BH1512-006	TTL	Connector	2.75	4.625	41
5/8-18	BH1522-006	ST	Connector	2.75	4.625	41
5/8-18	BH1512-009	TTL	Cable	4	4	41
5/8-18	BH1522-009	ST	Cable	4	4	41
5/8-18	BH1512-010	TTL	Cable	6	6	41
5/8-18	BH1522-010	ST	Cable	6	6	41