



**Display “Offline” Resolution For TACHTROL30<sup>®</sup>, TACHTROL10<sup>®</sup> and  
TACHTROL<sup>plus</sup><sup>®</sup>**  
BRC 2/8/11

“Display Is Offline” may be displayed on the front panel of a TACHTROL tachometer or remote display. In most cases this is a simple fix. Displays communicate to the tachometer through a local network, created by the tach, regardless of if they are part of the instrument (TT 10 & 30) or as a remote display (TTplus). Each display must have a distinct address to be properly orchestrated on the network and there can be up to 8, including the TT instrument display, on any local tach network.

1. From the front panel press F2 > Security
2. On the drop down menu verify Display Address is not “0”. It can be any number between 1 and 8. If there will be multiple remote displays connected it is best to use 1 for the tachometer.
3. If the display address = 0 it must be changed.
4. Use the down arrow (4) to navigate to Display Address.
5. Press Enter to toggle the address number. Set to the desired number. If there are additional TACHTOL<sup>plus</sup> units connected, each display must be a different number.
6. Press F1 to return to the main screen